



Pressure Dr

410-LPM

temperedwater.com

5330 East 25th St. Indianapolis, IN 46218 Phone (317) 261-1212 Fax (317) 261-1208



The master controller shall be of the thermostatic type with liquid-filled motor. The controller shall maintain the set point temperature during periods of fluctuating inlet pressures and temperatures. Valve construction will include a lead free brass body and replaceable corrosion-resistant components. The piston and liner are stainless steel. The mixing valve shall employ an adjustable setpoint range and high temperature limit stop. Each unit will be equipped with stop and check valves for each inlet and includes a dial thermometer. Cabinet is shipped separately.

Thermostatic Mixing Valve Eng. No. 86501

Model 410-CAB

CAP	40111	E3 - I	VIODE	L 410		
ressure Drop PSI	5	10	20	30	45	60
Valve Number				Capacity	,	
410-GPM	5	8	12	15	20	24

45

56


75

91

19 1/4 gpm when properly installed in recirculated system. The minimum flow of the Series 410 is 1 GPM.

FLOW CAPACITIES SINGLE STAGE - SERIES 410

30



FLOW OF WATER, GALLONS PER MINUTE

FINISH:	Brass Rough Chr Other		
TEMP. RAN 50° to 100 85° to 135 100° to 150 Special	°F °F	SET POINT 80°F 110°F 130°F	

CABINET SPECIFICATIONS:

STAINLESS CARBON STEEL

Body: 18 Ga. 16 Ga. Door: 18 Ga. 16 Ga.

Type 304 with Baked enamel painted Material:

No. 4 Finish

TYPE OF CABINET MATERIAL

Recessed Stainless Semi-Recessed Carbon Steel Surface Carbon Steel Box, □

Stainless Door


Cabinet includes lock with two keys. Hinged left side, piano type. For specifications on security cabinets, contact factory.






temperedwater.com

5330 East 25th St. Indianapolis, IN 46218 Phone (317) 261-1212 Fax (317) 261-1208





DIMENSIONS

Valve Number	Α	В	С	
410	14"	14"	6"	

Dimensions are for reference purposes only. For rough-in dimensions please refer to Lawler's Revit/BIM models found at temperedwater.com.

Inlets & outlet are 3/4" NPT. Add 4" to height and for flange.

Model 410-CAB Eng. No. 86501

Typical Installation

Install the mixing valve below the hot water tank or heater. If this is not possible, pipe in a heat trap as shown in Figure 1 with an approximate 2' drop.

Connect a tempered water return line as shown in Figure 1. This allows flow through both ports of the mixing valve during periods of no draw.

Install an aquastat at the tempered water return pump.

Install the water heater per manufacturer's instructions.

Figure 1

