

## SUBMITTAL DATA SHEET

5330 East 25th St. Indianapolis, IN 46218 Phone (317) 261-1212 Fax (317) 261-1208



# Series 61 Thermostatic Water Controller Eng. No. 84008

### **CAPACITIES – GPM SERIES 61**

Pressure Drop PSI	5	10	20	30	45	60	80	
Valve Number	Capacity – GPM							
61-10	2.5	3.5	5.5	8	10	12	14	
61-15	3.5	5.5	8.5	11	15	18	20	
61-25	6	10	14	18	25	30	34	

1/4 gpm when properly installed in recirculated system.

Exposed mixing valve shall be of the thermostatic type with liquid-filled motor. In the event of interruption of hot or cold water supply or thermostat failure, the valve shall be designed to restrict flow by use of a sliding piston control mechanism with reverse seat closure. The valve shall maintain output temperature for changes in inlet pressures or temperature. Valve construction shall have lead free brass body and stainless steel piston and liner.

Unit is completely assembled as shown. Includes dial thermometer and shut-off on tempered water outlet.

Piped and cabinet assemblies which have a downstream shutoff device shall include union end stop and check valves with removable strainer on each inlet.

FINISH:	Brass Rough Chro Other	ome	
VALVE:	1/2" 3/4"		
<b>TEMP. RAN</b> 50° to 100 85° to 135 100° to 150 Special	<b>IGE</b> °F °F °F	<b>SET POINT</b> 80°F 110°F 130°F	

### **CAPACITIES – LPM SERIES 61**

Pressure Drop PSI	5	10	20	30	45	60	80
Valve Number	Capacity – LPM						
61-10	9.4	13.2	22.8	30.3	37.8	45.4	53
61-15	13.2	20.8	32	41.6	56.7	68	75.7
61-25	22.7	37.8	53	68	94.6	113	128

Minimum flow for 61-10 & 61-15 is 1/2 Gallon Per Minute Minimum flow for 61-25 is 1 Gallon Per Minute







5330 East 25<sup>th</sup> St. Indianapolis, IN 46218 Phone (317) 261-1212 Fax (317) 261-1208



#### DIMENSIONS

Valve Number	A N.P.T.	B N.P.T.	С	
61-10	1/2"	1/2"	8-1/2"	
61-15	1/2"	1/2"	8-1/2"	
61-25	3/4"	3/4"	8-5/8"	

Dimensions are for reference purposes only. For rough-in dimensions please refer to Lawler's Revit/BIM models found at temperedwater.com.

# Series 61 Eng. No. 84008

## **Typical Installation**

Install the mixing valve below the hot water tank or heater. If this is not possible, pipe in a heat trap as shown in Figure 1 with an approximate 2' drop.

Connect a tempered water return line as shown in Figure 1. This allows flow through both ports of the mixing valve during periods of no draw.

Install an aquastat at the tempered water return pump.

Install the water heater per manufacturer's instructions.

## Figure 1

